




ATM Card Reader Cleaning Guide





EMV/CHIP Card Reader Cleaning

▶▶ STEP 1



Remove card reader cleaner from package.

▶▶ STEP 2



Insert card reader cleaner directly into card reader as you would a credit or debit card.

Insert and remove several times.

Flip cleaning card over and repeat process.

Your card reader should now be clean and fully operational. If you require further assistance, please call the DC Payments toll-free support line at **1.888.414.3733**.